

USASPEC

OWNER'S MANUAL

MODEL: DF-CHR AUX INTERFACE

THANK YOU FOR PURCHASING **USASPEC** PRODUCT, BEFORE OPERATION, PLEASE READ THESE INSTRUCTIONS.

Model DF-CHR AUX INTERFACE

DF-CHR is designed to interface the audio outputs from devices such as XM radio receiver, DVD player, digital music player, iPod, and games directly to your factory audio system with CD changer function controls. **DF-CHR** interface adapter has two AUX input ports namely AUX 1 and AUX 2 respectively. It is therefore able to interface two independent external audio sources to your factory radio.

This AUX interface takes the place of the CD changer; therefore it is not possible to have a 6DISC CD changer and **DF-CHR** AUX interface adapter simultaneously connected to your factory radio.

PACKAGE

USASPEC DF-CHR package contains the following:

- **DF-CHR** Interface adapter.
- CDL-CXi cable.
- Mounting Screw x 4.

APPLICATIONS

DF-CHR is applicable to the following Chrysler vehicles:

Chrysler	300M	98-04	Pacifica	04-05	Town & Country	01-05
	LHS	98-04	PT Cruiser	01-05	Voyager	01-05
	Concorde	98-04	Sebring / Cirrus	01-05		
Dodge	Caravan	01-05	Intrepid	98-04	Status	01-05
	Dakota	01-05	Neon	00-05	Ram	02-05
	Durango	01-03				
Jeep	Grand Cherokee	99-04			Wrangler	03-05
	Liberty	02-05				

**Note: DF-CHR is not applicable to Factory Navigation and DVD systems.
Radio must have a "MODE" or "CD-C" button.**

Note Applications are subject to Change, if you have any question, please consult with salesperson or go to www.usaspec.com to confirm vehicle make model applications.

INSTALLATION

- Step1. Remove the radio.
- Step2. Disconnect existing CD changer from the radio if there is one.
- Step3. Plug the CDL-CXi cable to the receptor at back of radio.
(For radios have "MODE" function button, use the gray square connector on CDL-CXi.)
(For radios have "CDC" function button, use the round metal end of CDL-CXi.)
- Step4. Plug the round din plug of the CDL-CXi to **DF-CHR** interface box.
- Step5. Connect the audio output of your auxiliary devices to AUX 1 or / and AUX 2 input jack on **DF-CHR** interface adapter.
- Step6. Reinstall the radio.

OPERATION

Turn ON your radio and press "CD" button. The radio will display "CD 6 Track 1". "CD 6 Track 1" gives access to AUX 1 port of **USASPEC DF-CHR** and "CD 6 Track 2" gives access to AUX 2 port of **DF-CHR**. Use the Track UP/DOWN button to switch between AUX 1 and AUX 2. Adjust VOLUME, BASS, TREBLE and etc. as you would normally do for the other program sources on the radio.

CAUTION

- Do not disassemble or alter the cable and interface adapter.
- Make the connections correctly.
- Do not cut away the wire sheath and use the power for other equipment.
- Do not install in locations which might hinder vehicle operation or hazards for vehicle occupants.
- Having the wiring and installation done by professional.
- Arrange wiring so it is not crimped or pinched.
- Do not use this product for purposes other than stated for the vehicle.

Note: Product specifications and designs are subject to change without notice.

iPod is trade mark of Apple Computer, Inc.

Chrysler is a registered trade mark of Daimler Chrysler Corporation.

LTI Enterprises, Inc.

167 Mason Way, Unit A2
City of Industry, CA91746
Tel: (626) 336-3836

Tech. Support
(626)890-6410